

UPDATED May 01, 2017



Eclipse and Aeroclipse are guaranteed safe for all sensors.

Canon cameras using the Type 1 (20mm) Sensor Swab Ultra

EOS-1D
EOS-1D Mark II
EOS-1D Mark II N
EOS-1D Mark III
EOS-1D Mark IV

Canon cameras using the Type 2 (17mm) Sensor Swab Ultra

EOS M
EOS 300 up to & including 750D
EOS 1000D
EOS 1100D
EOS 1200D
EOS 100D/SL1 up to & including 700D
EOS 7D; M II
EOS D30
EOS D60
EOS 10D, 20D, 30D, 40D;50D, 60D, 70D
REBEL T5

Canon cameras using the Type 3 (24mm) Sensor Swab Ultra

EOS 5D / 5Ds / 5Dr
EOS 5D Mk II, 5D Mk III, Mk IV
EOS 6D
EOS-1Ds, 1DS Mark II, 1DS Mark III
EOS-1DX, EOS-1D X Mark II (due May 2016)



Contax cameras using the Type 1 (20mm) Sensor Swab Ultra

N/A

Contax cameras using the Type 2 (17mm) Sensor Swab Ultra

N/A

Contax cameras using the Type 3 (24mm) Sensor Swab Ultra

Contax N Digital



Fuji cameras using the Type 1 (20mm) Sensor Swab Ultra

Finepix S1, S2, S3, S5 Pro

Fuji cameras using the Type 2 (17mm) Sensor Swab Ultra

Fujifilm X-A1
Fujifilm X-Pro1
Fujifilm X-Pro2
Fujifilm X-E1
Fujifilm X-E2
Fujifilm X-M1
Fujifilm X-T1 / X-T10

Fuji cameras using the Type 3 (24mm) Sensor Swab Ultra

Fujifilm X-T2



KODAK cameras using the Type 1 (20mm) Sensor Swab Ultra

Kodak DCS620, 620X, 760

KODAK cameras using the Type 2 (17mm) Sensor Swab Ultra

N/A

KODAK cameras using the Type 3 (24mm) Sensor Swab Ultra

Kodak DCS SLR/c, DCS SLR/n, DCS 14n



KONICA MINOLTA cameras using the Type 1 (20mm) Sensor Swab Ultra

N/A

KONICA MINOLTA cameras using the Type 2 (17mm) Sensor Swab Ultra

Konica Minolta Maxxum 5D & 7D

KONICA MINOLTA cameras using the Type 3 (24mm) Sensor Swab Ultra

N/A



LEICA cameras using the Type 1 (20mm) Sensor Swab Ultra

Leica M8

LEICA cameras using the Type 2 (17mm) Sensor Swab Ultra

N/A

LEICA cameras using the Type 3 (24mm) Sensor Swab Ultra

Leica M9, M-Mono 246, M-E 220, M 240, M 262, SL 601,

Leica T , Leica X,X-U



NIKON cameras using the Type 1 (20mm) Sensor Swab Ultra

D300/300s, D2X/s

NIKON cameras using the Type 2 (17mm) Sensor Swab Ultra

D1, D100, D1H, D1X, D200, D2H, D2Hs

D40/40X/50/60/70/70s, D80, D90, D3000/3100/3200, D5000,

D5100, 5200, 5300, 5500,

D7000, 7100, 7200

NIKON cameras using the Type 3 (24mm) Sensor Swab Ultra

D500 (23.5mm sensor, 24mm swab recommended)

Df, D3/D3s, D3X, D4, D4s, D5

D600, D610, D700/750, D800/800e/ D810, J1, S1, V1, V3



OLYMPUS cameras using the Type 1 (20mm) Sensor Swab Ultra

N/A

OLYMPUS cameras using the Type 2 (17mm) Sensor Swab Ultra

E1, E3, E5, E30, E300, E330, E400, 410, 420, 450
E500, 510, 520, E600, 620,
PEN E-P1, P2, P3, P5
PEN E-PL1/s, PL2, PL3, PL5
PEN-E-PM1 / M2
OM-D E-M10, E-M10 ii
OM-D E-M5
OM-D E-M1
OM-D E-M5 II

OLYMPUS cameras using the Type 3 (24mm) Sensor Swab Ultra

N/A



PANASONIC cameras using the Type 1 (20mm) Sensor Swab Ultra

N/A

PANASONIC cameras using the Type 2 (17mm) Sensor Swab Ultra

DMC-GF1, GF2, GF3, GF5, GF6
DMC-L1, L10
DMC-G1, G2, G3, G5, G6, G7
DMC-GM1, G10

DMC-GX1, GX7, GX8
DMC-GH1, GH2, GH3, GH4

PANASONIC cameras using the Type 3 (24mm) Sensor Swab Ultra

N/A



PENTAX cameras using the Type 1 (20mm) Sensor Swab Ultra

K-5 II /s

PENTAX cameras using the Type 2 (17mm) Sensor Swab Ultra

*ist DL, *ist DS, *ist D
K3, K5, K7
K-r, K-x, K10D
K100D / Super / K110D
K20D, K30, K50
K200D, K500, K2000 / K-m, K-01

PENTAX cameras using the Type 3 (24mm) Sensor Swab Ultra

K-1



SAMSUNG cameras using the Type 1 (20mm) Sensor Swab Ultra

N/A

SAMSUNG cameras using the Type 2 (17mm) Sensor Swab Ultra

GX10, GX20
NX1, NX5, NX10, NX11, NX20, NX30

NX100, NX200, NX210, NX300, NX500
NX1000, NX1100, NX2000, NX3000
NX1100, NX2000

SAMSUNG cameras using the Type 3 (24mm) Sensor Swab Ultra

N/A



SIGMA cameras using the Type 1 (20mm) Sensor Swab Ultra

SD9, SD10

SIGMA cameras using the Type 2 (17mm) Sensor Swab Ultra

SD1, SD1 Merrill, SD14, SD15

SIGMA cameras using the Type 3 (24mm) Sensor Swab Ultra

N/A



SONY: USE ECLIPSE OR AEROCLIPSE FOR ALL SONY DSLR'S.

SONY cameras using the Type 1 (20mm) Sensor Swab Ultra

N/A

SONY cameras using the Type 2 (17mm) Sensor Swab Ultra

SLT A33,/35/37/55/57/58/65/77/77 ii

A100/200/230/290/300/330/350/380/390/
A450/500/550/560/580/700

A5000, A5100, A6000, A6300

AQX-1
NEX3/3N/C3/5/5N/7

SONY cameras using the Type 3 (24mm) Sensor Swab Ultra

A99, A850, A900

A7/R & A7/R ii – **USE EXTREME CARE**